



Simply Rack & Warehouse Equip, Inc.
www.simplyracks.com
8560 N Interstate 35
Georgetown, TX 78626
512-869-2803

Below are photos and installation instructions for the cantilever:

1. Attach base to the column with 4 long bolts. Add the back anchoring kickplate to the column with the same long bolts. Use flat washer in front in front and locking washer in back in front of nut.
2. Add arms to the column with 4 M20 (3/4") bolts with locking washer in back next to nut. Repeat on all columns.
3. Stand the column and secure with a forklift while standing the 2nd column.
4. Install the 4 horizontals. Horizontals attach to the columns with 4 M12 bolts. The bolts are shared with a common column. Make sure to add the nut for the common M12 bolt while standing second column for stability, you will need to remove the nut when adding the 3rd column.
5. Install the 2 x-brace sets with 5 M12 bolts (4 on each corner and 1 in the middle)
6. Make sure system is level and add anchors. 2 anchors per base + 1 per kickplate in the back. Stagger the anchoring (example: front left/middle right/kickplate left)









